

## Operating Instructions Knee Tilt Mechanism



### **Seat Height**

Twist lever upwards to operate gas height adjustment. Pull out to enter free float mode, push in to lock.

### **Tilt Tension**

Counterbalances body weight when in free float. Turn clockwise to increase force.